INSTRUCTION MANUAL

Karaoke1 in Audio Card 4in one Speaker

S1

Manual

English 1-7
Deutsch 8-14
日本語 15-21
Français 16-18
한국어 22-28
Español 29-37
Italiano 38-46
Português 47-55
ไทย 56-58

Control Panel Introduction

1.Power On/Off Light
Long press for 3 seconds to power on/off.The light is white when the speaker is powered on. The light is red when charging.Short press the power button to switch lighting effects.
2.Power On/Off
Short press to switch two input modes accompaniment mode and Bluetooth mode.
3.Sound ON/OFF
Short press to turn on or off the speaker's external sound function.
4.Mic Volume Control
Short press to adjust between singing mode and listening mode.Long press to adjust the microphone volume. When the microphone is muted,it is automatically enabled by default at power-on.
5.Echo
Turn left to reduce the echo; turn right to strengthen the treble.
6.Mid
Turn left to reduce the midrange; turn right to strengthen the midrange.
7.Bass
Turn left to reduce the bass; turn right to strengthen the bass.
8.Mic
You can adjust the microphone volume by rotating left or right.

P1

Control Panel Introduction

9.Reverb
You can adjust the reverb volume by rotating left or right.
10.Monitor
You can adjust the speaker/monitor volume by rotating left or right.
11.Volume
Scene mode, the indicator light indicates that it has been switched to this mode.
12.Pop
Scene mode, the indicator light indicates that it has been switched to this mode.
13.KTV
Scene mode, the indicator light indicates that it has been switched to this mode.
14.ATV
Scene mode, the indicator light indicates that it has been switched to this mode.
15.Echo
Scene mode, the indicator light indicates that it has been switched to this mode.
16.Voice Change
Short press to switch between four different voice modulation modes.
17.Accompaniment
When open, it is in accompaniment mode, and when closed, it's in original sound mode.Long press a stereo sound.
17.Dubbing
When turned on, the vocals will be highlighted, and the sound of the music will be muted.Whether turned off the music and the vocals are balanced.
18.Internal plug
When plugged, the sound played by the computer can be recorded back to the computer. When the computer's sound is muted, the sound played by the computer can only be monitored and cannot be recorded back to the computer.
19.Receive
When the Bluetooth receiver function is turned on, the external voice is sent to the earphone, and there is no external voice when it is turned off.
20.Musical effect sound
Scene 5 special effects sounds, short press to play different sound effects.

P2

Interface Introduction

1.Charging
The charging port can be connected to 5V/2A charging head for charging.
2.STEREO Line
Is a stereo composite broadcast. It can also be connected to the phone's OTG port.
3.Earphone
Earphone socket connecting to 3.5mm plugs.
4.Line In
Interface is the earphone and 3.5mm plug.
5.Aux
Connection to mobile phone for broadcast、recording、 ringing.
6.Accompaniment
Pedal switch can be connected to the 3.5mm plug.

Connection diagram

Picture A. Schematic diagram of jack connection

P3

Connection diagram

Picture B. Line connection diagram



Picture C. Schematic Diagram of Family KTV Connection



P4

Connection diagram

Picture D. Computer accompaniment and computer live debugging diagram

After the sound cards connected to the computer and the computer has recognized the sound card
Open the computer's live sound debugging software (TYPE-C cable), then click on the microphone icon in the lower right corner of the computer, find the sound card and adjust the volume. The speaker displays "5" and the sound card's indicator light is on, indicating that the sound card has been successfully installed and recognized by the computer.
Note: Computers with Windows 10 and above system and Sound Function and standard USB protocol all support connection with sound card.

Picture E. Bluetooth connection diagram

P5

Connection diagram

(1).Mix the Bluetooth device "S1" is detected, click to start pairing, and it will prompt "Bluetooth connection" on the screen of the computer, and will prompt"Bluetooth is connected", as shown in Figure(1).Now you can select music Sent to the sound card via Bluetooth on accompaniment mode.

Picture F. Charging connection diagram



Common Problems and Solutions

Common Problems	Cause	Solution
The accompaniment cannot be turned on.	Check if the accompaniment pedal is connected to the 3.5mm plug.	Connect the pedal to the 3.5mm plug and turn on the accompaniment.
The live stream has no accompaniment.	Check if the live stream has the accompaniment function enabled.	Turn on the power and select the accompaniment mode on the accompaniment.mp3.

P6

Common Problems and Solutions

Common Problems	Cause	Solution
The power indicator light is not on.	Low battery level or battery depleted.	Charge the device. Recommended to use a 5V/2A charger.
The microphone has no sound.	Check if the microphone is muted.	Turn on the power. Adjust the microphone volume.
The speakers have no sound.	Check if the sound system is muted.	Adjust the audio system.
The microphone has no sound.	Check if the microphone is muted. Check the monitor volume is turned off.	Adjust the monitor volume. Adjust the audio system.
The sound card has no sound.	Check the monitor volume is turned off.	Adjust the monitor volume. Adjust the audio system.
The sound card has no sound.	Check if the sound card is connected to the computer.	Connect the sound card to the computer.
The sound card has no sound.	Check if the sound card is muted.	Adjust the sound card.
The sound card has no sound.	Check if the computer's sound is muted.	Adjust the computer's sound.
The sound card has no sound.	Check if the sound card is muted.	Adjust the sound card